

## How to Upgrade Gateway 2 Instructions

### Step 1

Download the Gateway2 Upgrade Zip (**testv08691A.zip**) file from this link :

<https://orphek.com/led/wp-content/uploads/atlantik/testv08691A.zip>

Get a USB flash drive with 2GB or more. Unzips the zip file and copy the 3 files to your USB flash drive to the root.

<https://youtu.be/b437DElains>

### Step 2

1. Plug in the USB Flash Drive with the files for upgrading into the USB port on the gateway.
2. Press and hold the upgrade button with a paper clip and then apply power to the Gateway. When the Orange LED stops flashing and stays ON, you can release the reset button.
3. During the process, about 5 minutes, the orange LED will flash fast and then flash slowly then again fast and slow. When the upgrade process is complete, the orange LED will stop flashing and remain on. A BLUE LED should come on briefly indicating the upgrade is complete.

[https://www.youtube.com/watch?v=9RGs2312\\_VA](https://www.youtube.com/watch?v=9RGs2312_VA)

The Orphek Gateway 2 has two internal Wireless antennas; One to communicate with the light and the other to communicate with your router. This video shows how to change the wireless channel so there will be no conflict and to improve the connection.

### Important !!!

At the time line 1:26 in the video you can see you need to click on both the white button and the reset button with a toothpick as seen in the video!

[https://youtu.be/Xj\\_T1Zl2\\_YQ](https://youtu.be/Xj_T1Zl2_YQ)

For more information please contact us at [contact@orphek.com](mailto:contact@orphek.com)